



5.2 - Exploded views

This part of the manual contains the exploded views of the FALCON 300 which will assist in gaining a thorough knowledge of the machine.


5.2.1 - Motor group




Transmission device (cont.d)



Vice system (cont.d)



5.2.4 - Base



Base (cont.d)

